



# Korry

*Illuminating. Always.*



## 787 Spares

### Line-replaceable components for 787 flight-deck control panels

Korry offers a complete list of line replaceable components to service all Flight Deck Control Panels used on Boeing 787 model aircraft, including control panels, pushbutton switches, annunciators and knobs. All part numbers are unique to the 787 and are identified in the tables on the reverse.

In addition, Korry provides other components necessary for repair and maintenance of the Flight Deck Control Panels. Our test equipment is needed to perform return-to-service testing for any repaired unit.

Korry can perform the repair or maintenance for any Flight Deck Control Panel.

Korry operates as a certificated air agency (repair station) under FAA regulation 14 CFR Part 145 and EASA Supplement EASA.145.4618 as an EASA Part 145 operation.

Our repairmen are certified under 14 CFR Part 65 to facilitate Issuance of Airworthiness Certification (8130-3 form) for return to service of repaired articles.

# Spares Provisioning Lists

## Control Panels

Part Number	Name	Location	787 Variant
410100-002	Electrical	P5	-8, -9
410200-001	Passenger Signs	P5	-8, -9
410300-001	Anti-Ice	P5	-8, -9
410400-001	Cabin Pressure	P5	-8, -9
410500-001	Hydraulic RAT	P5	-8, -9
410600-001	Fuel / Fuel Jettison	P5	-8, -9
410700-001	Air Conditioning	P5	-8, -9
411000-001	Cargo Fire / Engine Control	P5	-8, -9
411300-001	Blank Fuel	P5	-8, -9
411600-002	PFC / ADIRU / HR	P5	-8, -9
411700-002	Window Heat / Emergency	P5	-8, -9
411800-001	Cargo Heat / Misc. Broadband Sw.	P5	-8
411800-006	Cargo Heat / Misc. Broadband Sw.	P5	-8, -9
411800-008	Cargo Heat / Misc. Broadband Sw.	P5	-8, -9
411800-009	Cargo Heat / Misc. Broadband Sw.	P5	-8
411800-010	Cargo Heat / Misc. Broadband Sw.	P5	-8
411800-014	Cargo Heat / Misc. Broadband Sw.	P5	-8, -9
411800-015	Cargo Heat / Misc. Broadband Sw.	P5	-8, -9
411800-016	Cargo Heat / Misc. Broadband Sw.	P5	-8
411800-106	Cargo Heat / Misc. Broadband Sw.	P5	-8, -9
411800-108	Cargo Heat / Misc. Broadband Sw.	P5	-8, -9
411800-114	Cargo Heat / Misc. Broadband Sw.	P5	-8, -9
412100-001	Flight Deck Door	P8	-8, -9
412200-001	Aisle Stand Panel / Flood	P8	-8, -9
412300-002	Rudder Trim Panel	P8	-8, -9
412400-001	OBS / Audio / Ovrd	P8	-8, -9
412600-001	Engine Fire Panel	P8	-8, -9
412700-001	Blank Panel	P8	-8, -9
413000-001	Source Select Capt.	P2	-8
413000-003	Source Select Capt.	P2	-9
413100-001	Landing Gear	P2	-8, -9
413200-001	Source Select F/O	P2	-8
413200-003	Source Select F/O	P2	-9
413300-001	Master Warning Capt.	PX	-8, -9
413400-001	Master Warning F/O	PX	-8, -9
413700-002	Fwd. Bright / Heat Capt.	P13	-8, -9
413800-002	Fwd. Bright / Heat F/O	P13	-8, -9
413900-001	Clock / Mic Capt.	P7	-8, -9
414000-001	Clock / Mic F/O	P7	-8, -9

## Switches

Part Number	Description	Qty per Shipset
33986-001	Push Button, Mom, Rjct	2
33986-002	Push Button, Mom, Canc	2
33986-003	Push Button, Mom, Acpt	2
33986-004	Switch, Mom, Non-illuminated	2
33987-301	Switch, Alt, Wht/Amb 28V Abba	9
33987-302	Switch, Alt, Wht/Wht line/28V Abba	9
33987-303	Switch, Alt, Wht/Amb 28V Abba	4
33987-304	Switch, Alt, Wht/Amb 28V Abba	4
33987-305	Switch, Mom, Wht/Wht 28V Abba	3
33987-306	Switch, Alt, Wht/Amb 28V Abba	2
33987-308	Switch, Alt, Wht/Amb 28V Abba	6
33987-309	Switch, Alt, Wht/Amb 28V Abba	3
33987-312	Switch, Alt, Wht/Amb 28V Abba	4
33987-313	Switch, Alt, Wht/Amb 28V Abba	2
33987-314	Switch, Mom, Wht/Amb 28V Abba	1
33987-315	Switch, Mom, Wht line/Amb, 28V Abba	1
33987-316	Switch, Mom, Wht line/Amb, 28V Abba	4
33987-317	Switch, Mom, Wht line/Amb, 28V Abba	1
33987-318	Switch, Alt, Wht/Red, 28V, Abba	1
33987-319	Switch, Alt, Wht/Red, 28V, Abba	1
33987-323	Switch, Alt, Wfbar/Amb, 28V, Abba	1
33987-324	Switch, Mom, Red/Amb, 28V, Abba	2
33987-331	Switch, Alt, Wht/Wht, 28V, Abba	1
33987-336	Switch, Alt, Wht/Amb, 28V, Abba	2
33987-337	Switch, Alt, Wht/Amb, 28V, Abba	1
33987-338	Switch, Mom, Wht/Amb, 28V, Abba	1
33987-339	Switch, Alt, Wht/Wht, 28V, Bbbb	1
33987-340	Switch Alt, Wht/Amb, 28V, Abba	2
33987-341	Switch, Alt, Wht/Amb, 28V Bbbb	1
33987-342	Switch, Mom, Red/Amb, 28V, Abba	2

## Knobs

Part Number	Description	Qty per Shipset
33988-012	Annunciator, Fault, Amber	5
33988-104	Annunciator, APU Btl Disch, Amber	1
33988-106	Annunciator, Eng Btl 2 Disch, Amber	2
33988-107	Annunciator, Eng Btl 1 Disch, Amber	2
33988-116	Annunciator, Disc, Amber	1
33988-118	Annunciator, On Batt, White	1
33988-119	Annunciator, High, White	1
33988-120	Annunciator, Medium, White	1
33988-121	Annunciator, Low, White	1
33988-122	Annunciator, Fail, White	1
39193-001	Knob, Bar Pointer, 1.0 dia.	25
39194-001	Knob, Outer, 0.75 dia.	9
39195-001	Knob, Round 0.75 dia.	2
39196-001	Knob, Grip-Pull, 1.0 dia.	4
39197-001	Knob, Outer, 1.0 dia.	1
39198-001	Knob, Round, 0.50 dia.	9
39286-001	Knob, Grip-Pull, 0.70 dia.	4
39286-002	Knob, Grip-Pull, 0.70 dia. w/ line	6
RD733-103	Knob	1
SA808-102	Knob	1



For more information contact us at:  
+1 425-297-9700 or sales@korry.com

[www.korry.com](http://www.korry.com)

Korry Electronics  
11910 Beverly Park Rd.  
Everett, WA 98204

APPROVED FOR PUBLIC RELEASE | DISTRIBUTION UNLIMITED

The information and data given are typical for the equipment described. However, any individual item is subject to change without any notice